



Please contact us for a downloadable large print guide or details of our video guide

[www.kingsaccesstechnology.com](http://www.kingsaccesstechnology.com)

Designed in the United Kingdom by  
Kings Access Technology Ltd 

Copyright ©2018KINGSACCESSTECHNOLOGYLTD  
All designs, logos, information, software, ideas and images are the exclusive property of Kings Access Technology Ltd. 15 Oxford Road Yeovil, Somerset BA21 5HR UK. Registered in the UK and protected by International Law. UK Company Number 10255647

# User Guide

## Sonic 2 USB Memory Stick Player and Bluetooth Speaker

KA-STB021



*Ideal if you are: visually impaired, a senior citizen, living with alzheimer's, parkinson's, dementia, autism, reduced motor-function or other access challenges*

Included in the box

1. Sonic 2 player with rechargeable battery
2. Mains adaptor / charger (USB C)
3. User guide



### 1. Play / Pause button

Press button during playback to pause audio, and again to resume.

### 2. Track Back / Rewind button

Click to skip back a track or hold down to rewind within the current track.

### **3. Track Forward / Fast-forward button**

Click to skip forward a track or hold down to fast-forward within the current track.

### **4. Reset / Skip Book (folder) button**

Click to skip to the next book (folder) or hold down to reset to the beginning of track 1, book (folder) 1.

### **5. USB Port**

Insert stick into the port (nb - it will only fit one way).

### **6. LED Indicator:**

Red: charging (switches off on full charge).

Blue: Power on.

Blue flashing: playback.

Blue/red flashing: playback and charging.

Red flashing: low battery.

### **7. On / Off / Volume control**

Rotate clockwise to switch on. You will hear a mechanical 'click' and an audible tone.

### **8. Headphone Socket (round)**

Use headphones with a mini-jack (3.5mm) connector.

### **9. USB C Power / Charger socket**

## **Playing Memory Sticks**

Simply insert and switch on. The player will automatically find the

audio and start playing. Use the other controls to navigate the audio content.

### **Bookmarking**

The player will automatically remember the last position it played across multiple memory sticks.

### **Connecting with a Bluetooth source**

Connecting with a Bluetooth source does not require any buttons to be pressed on the player. Simply switch on the player (with no USB stick inserted) and search on your Bluetooth device (Phone, Tablet etc) for 'Sovereign' or 'Bluetooth Speaker' and then connect. On successful connection you will hear a tone played. NB - when a USB stick is inserted Bluetooth is disabled.

### **Battery and Charging**

We recommend your first charge be for 6-8 hours and thereafter charge for 1-2 hours as required. We recommend you do not leave the charger plugged in all the time but if you do please be aware this may reduce the batteries operating life.

To plug in the USBC charger please line-up and carefully insert until it is seated. Caution - minimal force is needed and excessive force or rough handling may damage the connector

To remove the battery, click out once the over has been removed. Line up the new battery with the gold contacts and replace the cover.

Low Battery Warning: Three beeps are played when the battery is low (about 5 mins before expiry). This is repeated 2 mins later and then every 10 seconds until the battery expires.

## Using Headphones

The headphone socket is located on the front of the player to the left of the volume control. Only 'mini-jack' / 3.5mm connectors will fit.

## USB C Charger / PSU



This Charger / PSU has been designed for ease of use and handling with the following features:

1. 3D tactile design for ease of identification and handling

2. USB C connector which is both reversable and compatible with other USB C devices
3. High contrast design, strengthened, woven cable

### **General Safety**

Do not allow this product to be exposed to liquids, steam or sand.

Do not leave where excessive heat can occur such as in a vehicle, in direct sunlight, on top of a heater or other heat sources.

Do not attempt to open or dismantle any part of this product.

There are no user-serviceable parts inside.

If any faults are discovered do not operate, disconnect from the mains and contact your point of purchase.

### **EU and BS Declaration of Conformity**

This product has been designed, tested and certified to meet the following standards:

Radio Equipment Directive 2014/53/EU

ETSI EN 300 328 v2.1.1(2016-11)

Draft ETSI EN 301 489-1 V2.2.0(2017-03)

Draft ETSI EN 301 489-1 V3.2.0(2017-03)

EN 62479: 2010

EN 60065:2014

EMC Directive - 2014/30/EU

EN 55032:2015

EN 55020:2007+A11:2011+A12:2016

EN 6100-3-2:2014

EN 6100-3-2:2013

BS 1363-1:2016+A1;2018

Bluetooth

Bluetooth: 4.2 Dual mode

2402-2480MHz, OP MAX 1.2dBm

### **Disposal and Recycling**

This product contains a Lithium battery and must be disposed of / recycled with an appropriate agency.

Do not put in general waste.